

1th	0421,0479,0511,0512,0520	NOKIA	0502,0720,0807
VALIN	0816	Northmende	0514
K	0417	Ortitech	0426
International	2004	Octagon	0522
Digital	2004	Openbox	2013
9	2010	Openel	2016
erster	2011	Oplex	0512
erision	0512,0520,0523	Opticum	2006,2016
-Nakla	0304,0305,0418	Pace	0394,0395,0400,0402,0405,0500
annon	0368	Pace	0614,0815,2001
id	0454	Palcum	0396
rand	0387,0512	Palladium	0421
R	0306	Palpat	0423
threim	0308,0309,0390,0419,0469,0499,0507,0522	Parasat	0619,0663
	0522	Parasonic	0473,0832
oetal	0522	Paranda	0520
sal	0497,0514,0520	Parasat	0455
mon	0503	Philips	0402,0424,0425,0460,0477,0488,0507,0518,0522,0503,0550,0531,0941
rico	0481,0482	Phonotrend	0513,0512
xus	0499	Pioneer	0474
e.Sel.	0504,0516	Polest	2006,2017
ernden	0497,0520	Preiser	0497
KCF	0394,0397,0392	Premier	0802
3000	0420	PremiumX	0501
agravox	0477,0630,0631	Primsat	0454
ambatan	0512,0514	Prosat	0405,0451,0479,0511,0523
atanz	0499	Protek	0504
aspro	0490	Provision	0514
ax	0520	PSR	0658
& B	0516	PTTELCOM	0515
ega	0499	Quelie	0511,0523
etronic	0496,0507,0511,0514,0522	Radio	0303,0520
elz	0383	Radio	0499
icrosat	0874	Radix	0409,0428,0430,0497
IVA	0494	Rainbow	0522
nerva	0883,0400,0484	RCA	0450,0818,0835
tsubishi	0489	RC-AK	0456
ME	0217	RFT	0489,0511
organs	0421,0497,0499,0512,2012	RMT	0860
olovra	2000	RM(RM2010)	0860
EC	0422,0470,0493	Fover	0523
eohemann	0421	RGS(Spanish)	0946
rosal	0845	SABA	0514,0520
edion Box	2007	Sagem	0518
elwork	0394	Saltura	0397,0398
elhaus	0520	Salora	0391,0418
ausel	2013	Samsung	0459,0475,0476,0477
ew Star	2015		

SAI 100	0601,0077	Technosat	0499, 2018
Sateco	0426	Technoset	0661, 0667, 0802
Satcom	0515,0516,0520	Technovet	0520
Satline	0522	Tedalex	0466
Sapartner	0514,0522	Telnicia	0471
Schacke	0522	Telnet	0516
Schwaiger	0516	Telnet	0522
Scientific	0482	Telnet	0508
Atlanta	0516	Telnet	0522
SEG	0512	Telemax	0514
Seleco	0512	Telemax	0432
SET	0839	Telemax	0398,0409,0428,0430,0469,0487
Siemens	0388	Telemaster	0513
Sigma	2007	Teletech	0512
Signal	0450,0550,0555	Televis	0512
Sintrack	0472	Thomson	0520,2009,2017
Skardin	0927,2002	Thom-Thomson	0394,0395,0400,0401,0402,0433
Sky Box	2007	Total	0465
Sky Digital	0800,0881	Tona	0512
Sky Master	0479,0511,0513,0516,0517,0523	Topfield	0509
Skymax	0499	Tooshiba	0442,0444,0508,0513
Skyvision	0512	TPS	0905
SL	0497	Triumph	0506
Sony	0472,0834	Tram	2005
Star	0459, 0470, 0802, 0446, 0868, 0871, 0875	Unbranded	0461
Strong	0389, 0423, 0426, 0400, 0492, 0308, 0514, 0522, 0804, 0865, 0868	Unidan	0403,0404,0406,0443,0830,0831
STS	0393	Unisat	0489
STV	0413	United States	0440
Sun Moon Star	0813	Universum	0520
Sunstar	0497	US Electronics	0417
Super Max	0846, 0846, 0849, 0850	Vector	0430,0407
Supex	0858, 0862, 0869	Ventana	0499
Tadiran	0017	Vievalat	0477
Tagra	0512	Vision	0519
Tantec	0386	Vortec	0459,0801,0855
Technisat	0400, 0420, 0420, 0430, 0431, 0407	Vortic Star	0801
		Vtech	0434,0507
		Wela	0497
		Wetelcom	0516
		Winer	0080,0387,0440,

210

Whitlighten	0511	Zehnder	0390,0507,0514
WISI	0409,0420,0435,0436,0437,0438	Zenith	0441,0444,0445,0446,0447
Woorisat	0514	Znwell	0821
XSAT	0500	Zodiac	0522
		Others	0820,0861

ABC	0452	Paragon	0806
Jerrild	0417	TADA	0448

CABLE Codes

Blaupunkt	0588	Pioneer	0545
Fisher	0528	Sanyo	0539
Hitachi	0530	Sharp	0531
Kenwood	0527,0531,0532,0533,0534	Sherwood	0540,0541,0577,0578
Lenco	0595,0596,0597,0598,0599,0600	Skardin	0544
		Sony	0617
		Technics	0542
		Yamaha	0543,0544
CD Codes		Parasonic	0538
		National	

Afreay	0688	Monyka	0684
Aiwa	0626,0649	Mullek	0638
Alba	0680	Neufrik	0684
AMC	0643	Onylo	0647,0653
APEX	0672	Orion	0686,3010
Aranel	0654	Orion	0683
ATLM	0627,0671	Pacific	0676,0677,0678,0679
BBK	3003,3004,3005,3006,3007,3008	Parasonic	0573,0574,0629,0639
Bentley	0635	Philips	0559,0675
BSIYB	0680	Phonotrend	0689
Bush(UK)	0680,0685,0689	Pioneer	0571,0658
Carwell	0622	Raile	0684
CineULTA	0689	RCA	0602,0661,0667
CONIC	0673	REC	0685
Daewoo	0660,3013	Red Star	0650,0652
Danca	0665	Roadstar	0685,0689
Denver	0689	Sampo	0688
Denzel	0684	Samsung	0637,0648,0666
Desay	0625	Sansul	0686
Diamond	0683	Sanyo	0681
Dual	0684	Schneider	0679
Eitex	0642	Schwaiger	0679
Elyxio	3000	SEG	0684
Encore	0688	Sharp	0628,3010
Erzer	0684	Skymaster	0666
Ferguson	0679	Soloi	0645
Goldstar	0633,0692	Sony	0575,0631,0632,0641,0657
Grundig	0655,0686	Taling	0659
Hamamkardon	0690	Tatec	0634
Hitachi	0684	Tebasar	0651
JMB	0686	Tevion	0683
JVC	0636,0684,3012	Thomson	0688
Kenwood	0572,0630,0663	Tokai	0684
Kiss	0684,3015	Toshiba	0571,0540
Lenco	0689	Universum	0682
Lesson	0687	Wesder	0699
LG	0682	Wharfedale	0687
Logik	0689	Wilson	3014
Magnavox	0571	Xoro	3017
Mania	3011	Yakumo	3018
Maxisul	0683,0688	Yamaha	0646
Maxview	0670	Yamataka	0684,3016
M & B	0670	Zenith	0570,0692
Microsoft	0619,0620	Others	0674
Mitsubishi	0662		

21

AUX Codes

BBK	3001,3002	Philips	0560(EQ)
Blaupunkt	0569(VHS)		0561(PIP)
Cadherine	0524,0525,0526(CTV)		0562(TAPE)
Danon	0564(TUNE)		0565(TUNE)
	0566(DECX)		0567(DCC)
Microsoft	0621(MCE)	ROTEL	0584(TAPE)
		Sony	0563(TAPE)
			0575(CDV)
			0618(TUNE)